## **8.2 LOADING CHARTS**

## 8.2.3. INTERCHANGEABILITY OF ULDs

Aircraft Type / Configuration(see ULD Technical Manual for loading	IATA S	Standa	rd Con	tainer C	ontour	s (see L	JLD Te	chnical	Manua	I Speci	fication	50/0.	Append	lix 'E' )
envelope)						· (000 ·				орос.		00,0,	pp 0	,
CHVCIOPO)	AB	С	D	EN	F	GH	K	L	М	Р	U	Х	Υ	Ζ
B707C	7.2				-	0	X	_		-	Ť		Х	X
B727C							Х							Х
B737C							Х							Х
B747 lower deck		Х		Х	Х		Х			Х	Х			1
B747F main deck	Х		Х				Х	Х	Х	Х		Х	Х	Х
B767 lower deck				Х	Х		0			0				1
B767F main deck	Х						Х		Х	Х			Х	Х
B777 lower deck		Х		Х	Х		Х			Х				
B777F main deck								Х				Х		
B787 lower deck		Х		Х	Х		Х			Х				
L100	Х						Х		Х	Х			Х	Х
L1011lower deck				Х	Х		Х			Х				
DC8F							Х						Х	
DC10/MD11 lower deck		Х		Х	Х		Х			Х				
DC10F/MD11F main deck	Х	Х					Х		Х	Х			Х	Х
A300 lower deck		Х		Х	Х	Х	Х			Х				
A310 lower deck		Х		Х	Х	Х	Х			Х				
A300-600 lower deck		Х		Х	Х	Х	Х			Х				
A300C/F main deck	Х								Х				Х	Х
A310C/F main deck	Х								Х				Х	Х
A300-600C/F main deck	Х								Х				Х	Х
A319/A320/A321/ lower deck						Х								
A330/340 lower deck		Х		Х	Х	Х	Х			Х				
A330F main deck	Х								Х				Х	Х
A340-500/600 lower deck		Х		Х	Х	Х	Х			Х				
AN12	Х				_		Х		Х	Х			Х	Х
IL76	Х						Х		Х	Х			Х	Х
IL86 main deck				Х	Х		Х			Х				
x Contour compatible with all airci	aft (see N	lote)												

## Note:

Certain aircraft types or equipment may not include the restrain hardware necessary to properly restrain some of the container base sizes applicable to the indicated contour. It is necessary to check with the carrier if the equipment of the aircraft considered allows carriage of the container size.